



VERSATILE MACHINE

USER GUIDE

- 1 LEVER
- 2 CONE
- 3 TRAY
- A STRAINER
- B FUNNEL
- C UPPER MOLD APPLE CUTTER (PLASTIC)
- D APPLE CUTTER BLADE
- E UPPER MOLD POTATO CUTTER (PLASTIC)
- F POTATO CUTTER BLADE



APPLE CUTTER & CORER




FUNCTION:
Cutter / apple corer, perfect for cutting apples into 8 portions.

USE:

1. Insert C to 1.
2. Place the item buttons C to 1.
3. Turn C tabs for a good grip to 1.
4. Set D to 2.
5. Place the apple in D.
6. Press the lever down to cut the apple and remove the core.

JUICER




FUNCTION:
Juicer, perfect for getting the juice citrus fruits (oranges, lemons, etc.).

USE:

1. Insert A to B.
2. Place the AB assembly to 2.
3. Cut orange in half and place it face down on A.
4. Press the lever down to extract the juice.

FRENCH FRY CUTTER



FUNCTION:
Potato cutter, perfect for french fries.

USE:

1. Insert E to 1.
2. Insert the E buttons element to 1.
3. Turn E tabs for a good grip to 1.
4. Set F to 2.
5. Peel the potato and put over F.


pujadas

INNOVATION & TRADITION
FROM BCN TO THE WORLD


VERSATIL MACHINE

INSTRUCCIONES DE USO

- 1 PALANCA
- 2 CONO
- 3 BANDEJA
- A COLADOR
- B EMBUDO
- C MOLDE SUPERIOR CORTADOR MANZANA (PLÁSTICO)
- D CUCHILLA CORTE MANZANA
- E MOLDE SUPERIOR CORTADOR PATATA (PLÁSTICO)
- F CUCHILLA CORTE PATATA



CORTADOR DE MANZANAS




FUNCIÓN:
Cortador / descorazonador de manzanas, perfecto para cortar manzanas en 8 porciones.

USO:

1. Inserte C en 1.
2. Coloque los botones del elemento C en 1.
3. Gire las pestañas de C para conseguir una buena sujeción a 1.
4. Fije D en 2.
5. Ponga la manzana entera en D.
6. Presione la palanca hacia abajo para cortar la manzana y sacar el corazón.

EXPRIMIDOR




FUNCIÓN:
Exprimidor, perfecto para sacar el jugo de cítricos (naranjas, limones, etc).

USO:

1. Inserte A en B para formar un conjunto.
2. Coloque el conjunto AB en 2.
3. Corte la naranja por la mitad y póngala boca abajo en A.
4. Presione la palanca hacia abajo para extraer el zumo.

CORTADOR DE PATATAS



FUNCIÓN:
Cortador de patatas, perfecto para patatas fritas.

USO:

1. Inserte E en 1.
2. Insertar los botones del elemento E en 1.
3. Gire las pestañas de E para conseguir una buena sujeción a 1.
4. Fije F en 2.
5. Pelar la patata y ponerla encima de F.

pujadas

INNOVATION & TRADITION
FROM BCN TO THE WORLD